



- Technical Requirements:**
1. Cabinet shell and door is connected with hinges and the door and hinges are connected through using d3.2 blind rivets(per picture shown);
 2. When the cabinet is locked in close, the door shall be flush with cabinet; and the door opening angle shall be more than 180°;
 3. When there is no key to open and in urgent use, just break the wire glass and directly open the latch lock by hand from inside.

10	DLX01-036-03-Y01	Marking	1			
9	GB/T818-2000	M4 × 16 Pan head screw	3	Steel		Galvanized
8	DLX02-037	Latch lock	1	Assembly		
7	DLX01-036-03	Wire glass	1	Glass 575 × 332 × 6mm		
6	GB/T6182-2000	M5 Hexagon locking nut	6	Copper		Nickel plating
5	DLX02-039A	Press plate	1	SUS304		
4	DLX01-036B-02	Door	1	SUS304		
3	GB12618-90	Blind rivet d 3.2	14	Aluminium		
2	DLX02-024	Hinge	1	SUS304		
1	DLX01-036B-01	Cabinet shell	1	SUS304		
No.	Drawing No.	Name	Q'TY	Material	Weight	Remark
			630 × 460 × 275	Code No.		
			Fire Cabinet	HC009		
			Assembly	W.T. ~15Kg Scale		
				Hydrotech		
Zone	Revision note	Date	Signature			
Drawn	Audit					
Checked	Approval					